



## Battery Clamp Cover 06+ Ford Fusion Instructions part # 555-0675 Parts List

<u>Qty.</u>	<u>Description</u>
1	Billet Battery Clamp Cover
1	M6 Flange Nut
1	#10-32 Set Screw
3	Flat Washers

### Instructions

Due to production line variances in the length of the battery clamp rod, installation involves a minor amount of trial-and-error.

1. Thread the set screw into the hole on the rear edge of the Billet Cover. Thread it in until the point just protrudes from the inside face.
2. Install 3 flat washers onto the battery clamp rod.
3. Position the Billet Cover over the battery clamp strap and battery clamp rod. If the battery clamp rod protrudes less than 1/4", remove 1 or 2 washers and recheck.
4. While ensuring that the Billet Cover lays flat on the clamp, tighten the set screw.
5. Install the M6 flange nut onto the battery clamp rod and tighten.



Thank you for choosing **STEEDA**. Any questions on these instructions contact us at (954) 960-0774 or e-mail us at [gofast@steeda.com](mailto:gofast@steeda.com)

