

STEEDA

Billet Aluminum Pedal Covers

Installation Instructions

1. Set the parking brake.
2. Remove the rubber pads from the clutch and brake pedal.
3. Hold the STEEDA Mustang pedal over the factory pedals and use them as a template to mark where the holes need to be drilled.

Note: The pedals are curved to fit most Mustangs. Due to the extremely large volume of cars manufactured by Ford, some pedals may be different. If necessary, the pedal covers can be bent to fit the vehicle better.

4. Drill holes in the factory pedals using a 9/64" drill bit
4. Carefully turn the screws into the pedals to tap threads into the hole.
5. Remove the screws and place the pedal covers over the factory pedals. Screw the pedal covers to the pedals. **Be careful not to over-tighten the gas pedal, or you may crack the plastic pedal.**

Note:

- Many Mustangs with automatic transmissions are equipped with a narrow flat gas pedal.
- Most V-8 Mustangs with manual transmissions are equipped with a wide curved gas pedal.
- If you have a V-6 Mustang, or if your car was converted from an automatic to a manual transmission, you may need a flat gas pedal to go with your manual transmission pedal kit. Different gas pedals are available from Steeda Autosports. Call 954-960-0774 for more information.