



Steeda Shifter Bezel 87-93

Installation Instructions

Note: Will also fit 79-86 if the bezel is carefully centered over the larger opening in the plastic trim plate

1. First remove the shift knob. Once removed, use your fingers on the inside part of the bezel (where the leather boot meets the trim) and lift up. The factory bezel will pop out.
2. With the factory shifter bezel removed, place the Steeda billet bezel on to the factory bezel. With the supplied drill bit, mark a starting hole through one of the screw holes on the bezel (pic. 1)
3. Remove the bezel and drill a hole through the plastic factory bezel. **Do not continue through the metal support ring for the leather boot, just the plastic bezel.**
4. Using the supplied screws, screw the Steeda bezel into the factory plastic bezel. Since the plastic is not tapped, you will need to back the screw in and out several times to achieve a flush fit (pic. 2). Repeat the process with the final 7 screws without removing the Steeda bezel.
5. Reinstall the assembly into the console and screw back on the shift knob.

