



Steeda Intake Spacer

4.6 Liter 3-Valve

Mustangs

Instructions for Part # 555-3106

1. Start by disconnecting the intake tube that connects to the throttle body from the mass air meter.
2. Unbolt the throttle body and place it off to the side. Use a pair of channel lock pliers and remove the 4 studs from the intake manifold that hold on the throttle body and discard, Pic 1 .
3. The Steeda intake spacer requires the use of the supplied gasket on the front and the factory one on the back of the spacer. Using the supplied 6mm bolts, bolt up the throttle body with the Steeda intake spacer bolted between the throttle body and the intake manifold, Pic 2. Reconnect the intake tube and you are finished!

