



STEEDA

2017 Fusion SPORT Throttle Body Spacer

Instructions for 555-3212

Installation

1. Unbolt the engine cover and remove it for access to the throttle body.
2. Loosen the hose clamp on the hose coming out of the throttle body, and remove the hose from the throttle body.
3. Remove the 4 bolts securing the throttle body to the intake.
4. Insert the Steeda throttle body spacer between the throttle body, and the intake, with the o-ring facing the throttle body.
5. Install and tighten the four 6mm bolts and washers that are included in the kit. Install the washers on the throttle body side below the heads of the bolts.
6. Reinstall the hose and tighten the hose clamp. Verify everything is tight, and enjoy! (Note: the hose end may need to be trimmed if the hose is pinched too much.)

