

STEEDA

FOCUS STRUT TOWER BRACE

Installation Instructions for Part #:555-5719

- 1) Remove the two nuts on each strut tower, which are closer to the engine. It is not necessary to remove the third (outer) nut.
- 2) Set the strut tower brace on the car with the holes in the end brackets over the studs on the strut tower.
- 3) Reinstall the nuts on the strut tower, over the strut tower brace brackets. Torque nuts to 18 ft-lb. (25 Nm).

It is highly recommended that you modify your stock plastic battery cover. With the Steeda strut brace installed it is very difficult to remove the plastic battery cover. This can present a problem if you ever need to jump-start your car and don't have access to tools to remove the strut bar. See the picture below for the simple modification.

