

STEEDA

2008 FOCUS CHROME MOLY STRUT TOWER BRACE

Installation Instructions for Part #:555-5721

- 1) Remove the two nuts from the Drivers side strut tower which are closer to the engine. On the Passenger side remove the outside nut and the one towards the front of the car. It is not necessary to remove the third nut.
- 2) Set the strut tower brace on the car with the holes in the end brackets over the studs on the strut tower. Look at the picture below to see how it's orientated.
- 3) Reinstall the nuts on the strut tower, over the strut tower brace brackets. Torque nuts to 18 ft-lb. (25 Nm).

