



Steeda Focus RS Adjustable Rear Swaybar Endlinks

Installation Instructions
Part #: 555-1043

Stock Rear Swaybar Endlink Removal

1. Support the car on a drive on lift, two post lift, or jack stands to do this install.
2. Remove the rear wheels for easier access to the necessary components.
3. Undo the nuts holding the factory swaybar endlink in place (indicated in Figure 1) by using a 6mm hex key and an 18mm box end wrench.



Figure 1: Factory rear swaybar endlink

Steeda Adjustable Rear Swaybar Endlink Installation

1. Set the Steeda adjustable rear swaybar endlink to the same length as the factory endlink, as shown in Figure 2.
2. Tighten the jam nuts using a 3/4" box end wrench to secure the rod ends in place.
3. Install the Steeda adjustable swaybar endlink on the vehicle and torque the provided nylon locknuts to 76 ft-lbs.
NOTE: Use 14mm box end wrench to hold the rod end stud in place.



Figure 2: Factory vs Steeda rear swaybar endlinks

NOTES:

- Endlinks come pregreased from Steeda.
- Lightly grease the endlinks via the grease fitting as a part of your regular vehicle maintenance.