



MADE IN AMERICA



STEEDA

Explorer SPORT Rear Trailing Arm

Instructions for 555-4092

Installation

1. Lift the rear of the vehicle and support with jack stands.
2. Unbolt and remove the factory rear trailing arms.
3. Install the Steeda rear trailing arms.
4. Lower the vehicle.
5. Torque to factory specifications.

NOTE: The vehicle must be torqued on the ground.

