



STEEDA



MADE IN AMERICA

Steeda S550 Non-Adjustable Rear Camber Arms

Installation Instructions for Part: 555-4127

Tools required

1. 15mm wrench
2. 18mm wrench
3. Torque wrench



Removal Instructions

1. Jack up your vehicle and place it securely on jack stands.
2. Remove the rear wheels.
3. Using a 15mm and 18mm wrench remove the outboard and inboard bolts which secure the stock camber arm. See Figure 1.
4. Remove the stock camber arm.

Installation Instructions

5. Place the end of Steeda non-adjustable camber arm with the Delrin inserts inside the factory slot on the subframe. Do not torque at this time. See Figure 2.
6. Install the tapered end into the recessed location on the factory knuckle. See Figure 2.
7. Torque the inboard bolt to 85 ft-lbs and the outboard bolt to 76 ft-lbs.
8. Repeat this process for the other side.

NOTE: An alignment is suggested after installing this part.



Figure 1: Stock camber arm



Figure 2: Steeda non-adjustable camber arm with the Steeda rear camber adjustment bracket (555-4126)