



Steeda S550 Mustang Driveshaft Safety Loop

Installation Instructions for Part: 555-5070



Tools required

1. 2 x 13mm wrenches
2. 18mm socket
3. 19mm socket

Disassembly:

1. Place the car on jack stands, making sure the vehicle is secure and safe to work under.
2. Using the 18mm socket unbolt the two rear transmission bracket bolts.
3. Place the upper half of the Steeda Driveshaft Loop above the driveshaft and let it hang.
4. Position the lower bracket in place, lining up the transmission bracket bolts. Then using the 19mm socket and the provided 12mm x 65mm hex head bolts, secure the transmission bracket in place along with the lower half of the Steeda Driveshaft Safety Loop. Blue Loctite is recommended. Torque to 83 ft-lbs.
5. Using the two 13mm wrenches, tighten the supplied 8mm bolts and nuts to 24ft-lbs.

Note: When tightening the 8mm bolts it's easiest to insert the wrench from in front of the transmission bracket.

