



Steeda S550 Mustang Tie Down Kit

Installation Instructions for Part #: 555-5202



Figure 1: Steeda S550 Front Tie Down Bracket

FRONT

1. Support the car on a lift or jack stands.
2. Remove the 4 bolts on the front of the factory cross brace indicated in Figure 1.
3. Slide the Steeda front tie down bracket under the factory cross brace.
4. Bolt it back into place using the factory hardware.



Figure 2: Steeda S550 Rear Tie Down Brackets

REAR

1. Mount the Steeda rear tie down brackets as shown in Figure 2.
NOTE: If used in conjunction with the Steeda IRS braces, place the Steeda rear tie down bracket under the IRS brace bracket.
2. Insert the threaded plate into the opening in the subframe behind the toe link (see Figure 3). Use the shorter 12mm bolt (with a washer) to secure the bracket to the subframe.
3. On the rear most part of the bracket, feed the longer 12mm bolt (with a washer) through the subframe and secure it with the serrated nut provided.
4. Repeat for the opposite side.



Figure 3: Steeda S550 Rear Tie Down Bracket Threaded Plate