



MADE IN AMERICA

STEEDA

Steeda S550 Front Spring Spacer Kit

(for use with 555-8139 S550 Camber Plates)

Installation Instructions: 555-8255



Use the instructions for 555-8139 S550 Camber Plates and replace the stud plate with the provided one in this kit. Use spacers as shown in Figure 1. The spacer provided in the 555-8139 kit MUST be used with the spacers provided in the 555-8255 kit. Each spacer used from the 555-8255 will raise the front of the vehicle 1/8".



Figure 1