



The world's #1 manufacturer for Ford
aftermarket parts since 1988.

Speed Matters

Steeda Maverick Competition Strut Tower Brace (2022-2026)

MPN: **555-5739**



Install Time: **1 hr**

Difficulty: The difficulty level is represented by five blue 'S' logos, indicating a moderate level of difficulty.



Parts List - 555-5739

Description	Quantity
Steeda Competition Strut Tower Brace	1
Strut Tower Bolts	4

Tools List

10mm Socket
13mm Socket
Needle-Nose Pliers

Trim Removal Tool
Jack
Jackstands

Preparing the Strut Towers



Step 1

Remove the 10mm bolt holding the plastic shield on top of the strut tower.



Step 2

Use a trim removal tool to remove the clips above the firewall and set them aside.

Preparing the Strut Towers



Step 3

Unbolt the 2nd 10mm bolt and remove the plastic shield. Then repeat for the driver's side.



Step 4

Use a jack and jackstands to get the front of your Maverick in the air.

Preparing the Strut Towers



Step 5

Remove the front two 13mm bolts holding the strut in place.



Step 6

Use a pair of pliers to remove the clip shown in figure 11. Repeat step 5 for the driver's side.

Preparing the Strut Towers



Step 7

Relocate the negative battery cable to the side of the strut tower as shown in figure 14.

Installing the Strut Tower Brace



Step 8

Bring the Steeda Strut Tower Brace into place and use the included bolts to align it. Get the threads started, but do not fully tighten them yet.

Installing the Strut Tower Brace



Step 9

Adjust the other side so the holes line up with the strut tower. You may have to adjust the position of the strut itself so everything lines up.



Step 10

Once aligned, tighten down all four strut tower bolts.

Installing the Strut Tower Brace



Step 11

Replace the clips above the firewall. Torque the strut tower bolts to 22 lb-ft. After that, your installation is complete!



2281 Hammondville Road 2019 Steeda Way
Pompano Beach, FL 33069 Valdosta, GA 31601

<https://www.steeda.com>